

FIG.1

000000-000000




FIG. 2




FIG. 3

668120-12802200

065430-1E302200




FIG.4




FIG.5




FIG.6

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

SCREEN OF PC (D10)




FIG.7(a)

SCREEN OF THE DIGITAL CAMERA (D10)




FIG.7(b)

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

SCREEN OF PC (D12)




FIG.8(a)

SCREEN OF DIGITAL CAMERA (D12)




FIG. 8(b)

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

SCREEN OF PC (D13)




FIG.9(a)

SCREEN OF DIGITAL CAMERA (D13)




FIG.9(b)



DISPLAY AREA CHANGE IN ACCORDANCE WITH DISPLAY  
MAGNIFICATION RATES CHANGE AT DIGITAL CAMERA (D11)




FIG. 10

50% DISPLAY AT DIGITAL CAMERA (D20)




FIG. 11(a)

DISPLAY AREA CHANGE IN ACCORDANCE WITH DISPLAY  
MAGNIFICATION RATES CHANGE AT DIGITAL CAMERA (D21)




FIG. 11(b)

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

100% DISPLAY AT DIGITAL CAMERA (D30)




FIG.12

668760-12804260

APPROVED	O.G. FIG.	
BY	CLASS	SUBCLASS
DRAFTSMAN		

WARNING SCREEN AT PC (D40)




FIG.13(a)

WARNING SCREEN AT DIGITAL CAMERA (D40)




FIG.13(b)




FIG.14

668120-12802200

REGISTRATION OF ACTION TO FUNCTION KEY (D50)

REGISTRATION CHANGE OF F1 KEY
<u>TRANSFER DATA</u>
SPECIFY FOLDER TO WHICH DATA ARE TRANSFERRED
CHANGE SCREEN DISPLAY MAGNIFICATION
TURN OFF POWER SOURCE OF PC
DISPLAY IMAGE DATA IN PC
EXECUTE APPLICATION IN PC
TRANSFER IMAGE TO PC IMMEDIATELY AFTER PHOTOGRAPHING
PRESS UP KEY/DOWN KEY TO SELECT CONTENT OF REGISTRATION AND PRESS SHUTTER BUTTON TO EFFECT

FIG.15